

SureStrike™

Semi-Auto Caliber Adapter



This adapter kit will allow the standard 9mm SureStrike™ Laser Cartridge to be used in handguns with different calibers.

This package includes:

- Includes UhrSecure™ Safety system
- 45 ACP Adapter ring
- 40 S&W Adapter ring
- 10mm Adapter Ring
- 45GAP Adapter Ring
- 357 Sig Adapter Ring
- Other

We make shooters better! Spend less effort, time, and money by practicing with today's best personal training system anytime, anywhere!

This product is patented under the USA patent law. The User is hereby placed on notice of Laser Ammo rights as listed on www.laserammo.com

Product of Laser Ammo USA Inc.
Phone: 516-858-1262 (U.S)
Proudly Made In Israel | Assembled in USA
www.laserammo.com



User Guide Inside

Caliber Adapter / Adapter Kit

SureStrike™

Semi-Auto Caliber Adapter



SAFETY



IMPROVES ACCURACY



FIRING PIN ACTIVATED



NO VIBRATION SENSITIVITY



Instructions

Step 1 - Safety

- Unload the weapon
- Physically and visually inspect the chamber, bore, and magazine well to ensure that all ammunition has been removed.
- Store ammunition in an area that is separate from your training area.


⚠️ Always personally verify that all ammunition has been removed before training.

Step 2 - Installation

- 1 - Unscrew the action back cap from the laser module.
- 2 - Place the adapter, with the threaded end up, on the end of the laser cartridge.
- 3 - Carefully engage the thread. Please note the threading on the adapter is to engage AFTER the adapter is placed on the laser cartridge.

Caution: Do not use force.

- 4 - Insert the battery into the laser module, plus sign up, and screw the action back cap onto the exposed threading.



Step 3 - UhrSecure™ Safety System Installation

After inserting the laser cartridge into the chamber, insert the safety pipe down the barrel (A). While pressing lightly on the back of the laser with one finger, thread the safety pipe into the laser cartridge until you feel mild resistance. Do not over tighten the pipe. Screw the safety nut onto the safety pipe until it tightens against the barrel (B).

This side connects to the laser



This side connect to the safety nut

For barrels length longer then 4.1" connect the pipe extension to the safety pipe by threading them tightly together, before inserting the pipe. (C)



Using the SureStrike™ Laser Cartridge not according to the user guide will void the warranty.

No liability is expressed or implied for damage or injury as a result of installation or use of this product. Warranty is limited to the replacement or repair of the original product only.